


SPARE PARTS LIST


PRODUCT GRAPHIC REPRESENTATION



If the required spare parts cannot be found in this list, please contact the dealer.

DYNAMIC 520 START - 829383

DIAGRAM



DYNAMIC 520 START - 829383

SPARE PARTS LIST

REF.	DESCRIPTION	CODE	REF.	DESCRIPTION	CODE
1	RECTIFIER PROTECTION	112183	18	FOOT	322798
2	TIMER 16A 250V 60MN SU 280°+PM	112016	19	FRAME	322799
3	KNOB FOR TIMER	112296	20	POCKET	362052
4	KIT THERMOSTAT	981967	21	BOTTOM	644783
5	SWITCH	122381	22	DASHBOARD KIT	981256
6	SWITCH	122400	23	WHEELS AXLE	681055
7	THERMOSTAT	121716	24	COLORADO 150B WORK CLAMP 150A	712001
8	CABLE 16MMQ 2M- POSITIVE	980318	25	COLORADO 150R POSITIVE CLAMP 150A	712002
9	MAINS CABLE 2 M SCHUKO PLUG	132009	26	FUSES 80A 20 PCS	802260
10	AMPEREMETER	152267	27	FUSE HOLDER	980036
11	TRANSFORMER 230V	168014	28	BACK PANEL KIT	980302
12	HANDWHEEL	312053	29	RECTIFIER KIT	990902
13	HANDLE	312399	30	COMPLETE TERMINAL KIT D.33MM	990162
14	FUSE COVER	322051	31	INSULATING WASHERS KIT	990163
15	CABLE BUSHING	322112	32	CABLE 16MMQ 2M- EARTH	980366
16	FIXED WHEEL	322201	33	WHEEL LOCKING RING	322102
17	FRONT PANEL	322796			